MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030

E-mail: info@merc-automations.gr

WWW.MERC-AUTOMATIONS.GR

ME-MPA10

MANUAL



WWW.MERC-AUTOMATIONS.GR

MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

Brief Description

Dear User:

Thanks for your trust.

Please read this user manual carefully before using barrier gates.

The manual includes: main functions (our own advantages), dimensions, parameters, main board wiring diagram, installation instructions, testing, and packing list.

The user manual can help you to know more details about barrier gate, such as mechanical working theory, using guide, matters need attention.

We should use the barrier in right way to ensure the working life.

The user manual also analyzes some problems which maybe appear during using. And you can find out the way to solve each problem in the manual.

At the same time, we sincerely hope that you can give us some suggestions to make our barrier gates better and better.

Thanks!

Table of Contents

Product Features
Mechanical features---------- 03
Electrical features----------03
Safety features----------03
Model & Parameters
Models----------04
Parameters---------- 04
Directions----------04
Housing structure----------05
Boom type ----------06
Mechanism Structure
Barrier structure---------- 07
Inner structure---------- 08
Machine core structure---------- 09
Spring hanging hole illustration----------09
Installation Instructions
Installation----------10
Instruction details----------10
Debugging, Problem & Solving way
Debugging instructions----------12
Problem & solving way----------12
Function Board Wiring & Setting
Wiring diagram----------13
Board parameter settings----------14
Parameter debugging----------14
Using & Maintenance
Using instructions----------17
Maintenance----------17
Service Items & Packing List
Service items----------18
Packing list----------18
Guarantee Card----------18

MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

1. Mechanical features

● Nice designed cabinet: strong, waterproof, can be used outside.
● Integrative machine core: all part is made by mold, so all parts can be more accurate. And so, the barrier gate can be much more stable;
●100W integrated gear reducer, saving energy, motor with fan, prevent overheating, could working 24 hours without stop: Drive Steady, Noise Lower, Structures Compact, can realize self-locking;
●Accurate link mechanism: link mechanism can release boom's shake and motor load, so the barrier gate can move more stable and barrier gate's working life can be longer;
●Lock or open the boom by hand: we can turn motor handle to lock or open the boom when power is off.

2. Electrical features

●High integrated level, Powerful function;
●Shut down functions (motor will be shut down automatically after 6 seconds) and thermal protection functions can effectively protect our motor;
●Intelligent limited sensor to check open & close position automatically
●Anti-smash function
●Open and close speed are adjustable
●With LED indicator, easier to use and maintenance.
●Imported high-power MOSFET, contactless control motor switch
●Using imported photoelectric isolated protection circuit to ensure signals' stability;
●Support standard remote control and 25 groups can be added
●Using imported Magnetic core transformer to ensure working performance in damping situation;

3.Safety features

●Auto bounce back function, make sure car and facilities' safety
●Pressure sensor - Anti-crash functions: If the boom meets something during closing process, the boom will be opened automatically;
●Loop detector - Anti-crash functions: If car stands under the boom, the barrier gates cannot be close. And the barrier gates will be closed automatically when the car passes the boom;
●Open first functions: no matter the boom locates any position, it will be opened if barrier gate gets open signal;
●Plastic strips: we can install plastic strip into our boom, it can decrease accident damages.


1.Dimensions

Boom type	Boom Length(M)	Open time(S)	Close time(S)	The height of boom support
LED Arm	≤3	1.8	2	890mm
	≤4	3	3.5	
Telescopic boom	≤3.5	1.8	2	
	≤4.5	3	3.5	
	≤6	5	6	

2.Parameters

Voltage	DC24V
Motor power consumption	100W
Working temperature	-30℃~80℃
Humidity	≤90%
Boom length	≤6M
Open/close time	1.8S~3S/3S~6S
The height of boom support	890MM
Remote control distance	≤30M
IP	IP54
Input interface	Switch signal
Remote control frequency	430.5MHz

3.Direction




Left-hand version

Right-hand version


MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

4.Housing structure




5. Boom type



MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr


1. Barrier structure



NO	Name	Quantity
1	Cabinet	1
2	Arm	1
3	Hexagonal socket screw M8*65	2
4	Flat gasket φ8(SUS304)	2
5	Arm cover	1
6	Arm holder	1
7	Hexagonal socket screw M8	2

2. Inner structure


Its internal structure is operated by the output shaft of the all-gear reducer, and the movement is transmitted to the main shaft through the plane four-bar linkage mechanism, and the high-precision control system is used to accurately locate the position of the boom during operation, so as to realize the control of the boom. (Please refer to the illustration for details)



MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

3. Machine core structure



4.Spring hanging hole illustration

Barrier can use different length boom. Should change hole to meet different length.

Boom type	Boom length	Spring quantity&type
Straight boom	L≤4M	2*φ4.5
	4M＜L≤6M	2*φ5.5
folding boom	L≤4M	2*φ4.5
	4M＜L≤6M	2*φ5.5
fence boom	3.5M＜L≤4.5M	4*φ5. 5
	4.5M≤L≤5M	2*φ5. 5+2*φ6. 0

Notes: we must change spring type and hole, adjust the corresponding parameters if we change boom length.

1.Installation

- Check packing list to make sure all in right way
- According to barrier arm direction and actual situation to confirm fix place. If ground isn't concrete foundation or it is a slop, suggest to build a horizontal concrete foundation; After installation, barrier box should be perpendicular to ground
- According control center or security room position, reference (GB 232 electrical device installation and check before acceptance standard)'s relative rules to set power wires and signal wires (the two type wires should be set in different pipes)
- Use expansion screw (follow packing list part to confirm install number) to fix barrier gate cabinet then start to use
- Adjust boom arm to horizontal position by hand switch to confirm boom holder fix position (this step is optional)
- Connect and check all wires to barrier main board according to wiring diagram

Notes: Should cut off power during installations.

2.Instruction details

1)Line pre-buried

build concrete basement if it is needed (basement size should be bigger about 100-150mm than barrier base size). Bury power wires and signal wires between barrier and control center.

2) Fix barrier box

Choose the right place and fix barrier box by expansion screw.

3) Install boom

After fix barrier cabinet, install boom arm onto arm holder. Confirm boom arm in right place then fix screws. If we need to install barrier arm holder, adjust arm to horizontal position by hand switch to check holder fixing position, then fix arm holder.


4) Install other devices

You can connect and debugging other devices according to wiring diagram.

MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

5)Install loop detector



5.1. Draw loop coil shape: width is 1000mm, length depend on arm length, two sides is narrower than the arm 700mm to 1000mm, make a chamfer at 4 corners to prevent wires damages.
5.2. Use cutting machine to cut a groove according to the draw. Groove dimension: width 3-5mm, depth: 30mm, and cut a groove to barrier gate cabinet.
5.3. Put one end of the coil with enough length into cabinet, then circle it along the groove 5 times, then twist wires and connect them to loop detector ports 7 & 8.
5.4. Test the loop sensor to sure all right. Then use cement to bury the groove.

1.Debugging instructions

Item	Test way
Boom arm is not on horizontal /vertical position	1.Loosen the two locking screws on the spindle arm, rotate the boom to the horizontal position, and then tighten the screws. 2.Manually learn the open and close limits again by F04.
Arm shake during open	The parameters of F23 is too small, enlarge it
Arm shake during close	The parameters of F28 is too small, enlarge it


2.Problem & solving way

No	Problem	Reason	Solving way
1	Power indicator light is off, press button, no response	1. Don't connect power	1. Connect power
2	Power indicator light is on, but remote controller doesn' t work	1. Remote control code doesn' t match 2. Receiver module doesn' t work 3. Same frequency interference 4. Didn't learn the remote	1. Recode 2. Change receiver module 3. Change other frequency 4. Learn the remofe
3	Power light and working light are on, but motor doesn' t work	1. Motor wire loose	1.Reconnect wires
4	Limited sensor doesn't work	1.Limit sensor learning is wrong	1. Relearn limited position
5	Remote control can' t work	1.Battery is power off 2.The control is broken	1. Change battery 2. Change remote control
6	Control board display E1	1.Motor wiring error 2.Motor wire not connected 3.Control board motor interface is damaged 4. Motor error	1.Check motor wires and hall wires 2.Connect motor wires 3. Replace the control board 4. Replace the motor

MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

1.Wiring diagram



2.Board parameter settings

A.Parameters:

F-01 Set barrier direction
F-04 Set open & close position
F-09 Set open angle
F-10 Set close angle
F-13 Set bounce back strength
F-14 Set bounce back time
F-15 Set angle to close loop sensor
F-16 Set auto-close time without loop sensor
F-21 Set open speed
F-23 Set first angle to slow down during open
F-25 Set deceleration speed during open
F-26 Set close speed
F-28 Set first angle to slow down during close
F-30 Set deceleration speed during close
F-40 Set delay close time with loop detector

B.Parameter debugging

Note: The equipment has been debugged well before leaving the factory, and the barriers and arms can be installed directly. It is recommended not to modify the factory parameters casually.

1. Select the direction of the barrier: firstly, ensure motor wire is correct, then long press “Function/Save” button for 3 seconds, the LED will display F00. Press the “Open” button,When the LED displays F01, press the “Confirm/Stop /Copy/Delete” button, the LED displays the device direction, "□-- "represents the right direction, "--□" represents the left direction, choose the direction according to the actual situation. After the selection is completed, press the “Confirm/Stop/Copy/Delete” button, then press “Function/Save” button for 3 seconds to save the data.
(After this option is completed, it needs to be powered off and restarted to take effect).
2. Manual learning Open & Close position: When the LED displays F04, press the "Confirm" button, then press the "Close" button to change the value to 02, press the "Confirm" button again, the controller will restart, and then press "Open", LED will displays 01, and the barrier will stop after hitting the Open position. Keep press "Close" until the boom is vertical, then press and keep the "Confirm" for 2 seconds and release it, the LED displays 02, start to manually find the Close position, keep press"Close" until the boom reaches

MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363
SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

the Close position, press and keep the "Confirm" for 2 seconds and release it, wait for the LED displays 00 to indicate the completion of learning. (If there are eaves, etc., you can choose 03 for F04, and learn the position manually first close and then open).

3. Set Open angle: When the LED displays F-09, press "Confirm" to enter the opening angle adjustment, and then press "Open" or "Close" to adjust the opening angle. The larger value , the larger opening angle. The smaller value, the smaller opening angle. Press "Confirm" to save the data after the adjustment is completed.

4.Set Close angle: When the LED displays F-10, press "Confirm" to adjust the angle of closing, and then press "Open" or "Close" to adjust the angle of closing. The value of 30 represents the level of the boom. If it is larger than 30, the boom will deviate in the direction of opening. If the value is less than 30, the boom will deviate in the direction of closing. The larger the value, the larger the angle of deviation of the boom in the direction of opening. The smaller the value, the smaller the angle of deviation of the boom in the direction of opening. Press the "Confirm" to save the data.

5.Set bounce back strength: When the LED displays F-13, press "Confirm" to enter the adjustment of the strength of rebounding when encountering resistance, and then press "Open" or "Close" to adjust the strength of rebounding when encountering resistance. The larger the value, the larger the strength of rebound when encountering resistance. The smaller the value, the smaller the strength of the rebound when encountering resistance. After the adjustment is completed, press "Confirm" to save the data. (Adjusting this parameter may cause misjudgment by the controller, it is not recommended to change the value of this parameter at will)

6.Set bounce back time: When the LED displays F-14, press "Confirm" to enter the adjustment of the rebound response to resistance, and then press "Open" or "Close" to adjust the reaction time of the rebound when the resistance is encountered. The larger the value, the longer the reaction time of the rebound. The smaller the value, the shorter the rebound reaction time when encountering resistance. After the adjustment is completed, press "Confirm" to save the data. (Adjusting this parameter may cause misjudgment by the controller, it is not recommended to change the value of this parameter at will)

7.Set angle to close loop sensor: When the LED displays F-15, press "Confirm" to enter the adjustment of rebound reaction when encountering resistance, and then press "Open" or "Close" to adjust the angle value of loop sense shielding. Larger value, the larger the loop sense shielding angle. Smaller value, the smaller the loop sense shielding angle. Press "Confirm" to save the data after the adjustment is completed.

8.Set auto-close time without loop sensor: When the LED displays F-16, press "Confirm" to enter the delay closing adjustment. 00 means that the delay closing function is turned off, and 01-99 represent the delay closing time when there is no loop sense. You can set it according to your needs, and the unit is second. After the adjustment is completed, press "Confirm" to save the data.

9. Delayed closing adjustment with loop sensor: When the digital tube displays F-40, press "Confirm" to enter the delayed closing adjustment, 00 means that the delayed closing function is turned off, and 01-99 represent the delayed closing function with loop sense. The time can be set according to your needs, and the unit is second. After the adjustment is completed, press "Confirm" to save the data.

10.Set open speed: When the LED displays "F-21", press "Confirm" to enter the opening speed adjustment, and then press "Open" or "Close" to adjust the opening speed. The larger the value, the faster the opening speed. The smaller the value, the slower the speed, press "Confirm" to save the data after the adjustment is completed.

11.Set first angle to slow down during open: When the LED displays "F-23", press "Confirm" to enter the adjustment of the first deceleration angle of the boom opening, and then press "Open" or "Close" to adjust the first deceleration angle of the boom opening. The larger the value, the larger the deceleration angle of the boom opening. The smaller the value, the smaller the opening deceleration angle. After the adjustment is completed, press "Confirm" to save the data.

12.Set deceleration speed during open: When LED display "F-25", press the "Confirm" button to start setting, and then press "Open" or "Close" button to adjust the opening deceleration speed.The larger the value, the faster the opening deceleration speed, the smaller the value, the slower the opening deceleration speed. After the setting is completed, press the "Confirm" button to save setting.

13.Set close speed: When LED displays "F-26", press the "Confirm" button to start setting, and then press "Open" or "Close" button to adjust closing speed. The larger value, the faster speed, the smaller value, the slower speed. After the setting is completed, press the "Confirm" button to save the data.

14.Set first angle to slow down during close: When LED displays "F-28", press the "Confirm" button to start setting, and then press "Open" or "Close" button to adjust the first deceleration angle during close. The larger the value, the larger angle. The smaller the value, the smaller angle.After the setting is completed, press the "Confirm" button to save setting.

15.Set deceleration speed during close: When LED display "F-30", press the "Confirm" button to start setting, and then press "Open" or "Close" button to adjust the closing deceleration speed.The larger the value, the faster the closing deceleration speed, the smaller the value, the slower the closing deceleration speed. After the setting is completed, press the "Confirm" button to save setting.

16.Learning and deleting remote control codes: If you need to learn remote control codes, first press "Copy" button until the LED displays "1" and at the same time press any button of remote.Back to menu interface after successful registration, and then press "Copy" key for 5 seconds on the main interface until the LED displays 0000, all the registered remote will be deleted.

MAIN OFFICE
Add: Delfon 13, Athens Greece, 173 42
Tel: +30 210 994 8300
Mob: +30 698 070 1363

SECONDARY OFFICE
Add: Leoforos Athinon 62 & Thivon , Athens Greece, 121 31
Tel: +30 210 598 3030
E-mail: info@merc-automations.gr

1. Using instructions

- Before use, make sure all wires are ok.
- Press open button, the boom will open to right position and stop.
- Press close button, the boom will close to right position and stop.
- During closing, if car pass the barrier. Press open, barrier will stop and open. Press stop, barrier will stop.
- Power off, use handle to open the boom. Power on, press close button, then the barrier can be used.

2. Maintenance

- Clean the housing surface regularly;
- Check wiring diagram regularly, if some wires loose, fix them back;
- keep the barrier in aeration-drying atmosphere to ensure the stability and working life;
- Check transmission shafts regularly, if loose, fix them back;
- Check spring regularly; ensure spring is in good situations.
- Check the connection between housing and grand regularly, ensure housing is well fixed.

1. Services items

- The warranty is 1 year
- Provide maintenance all the life time

Not included free maintenance under the damage of following situation

- Damages caused by wrong installation (please follow instruction)
- Using unstable power supply which beyond product's working range or not compliance with national electricity use safety standard
- Irresistible factors, like natural disasters
- Incorrect usage

2. Packing list

NO.	Name	Unit	Qty	NO.	Name	Unit	Qty
1	Cabinet	set	1	2	Spare parts	set	1
3	User manual	pcs	1	4	Remote controller	pcs	2
5	Guarantee card	pcs	1	6	Key	pcs	2

Guarantee card

Customer		Tel	
Address			
Purchasing time		Model	

1. Please write your information carefully, only stamped guarantee card is valid;
2. Guarantee is 1 year;
3. Guarantee does not cover any problems caused by actions not following our user manual.